







PXT FREE FLOATING SUPER SLIM RAIL (FFSSR)
INSTALLATION ILLUSTRATION:



PXT FREE FLOATING SUPER SLIM RAIL (FFSSR) PARTS LIST:




PXT FFSSR



| (4) STANDARD #10-24 HEAD SCREW | (2) LOW #10-24 HEAD SCREW | (1) FFSSR BARREL NUT | (3) BARREL NUT SHIM |
|---|---|---|---|
|  |  |  |  |



PXT FFSSR INSTALLATION STEPS: 1 - 5




CORRECT ALIGNMENT




FFSSR INSTALLATION STEPS: 6 - 13


CHECK RAIL ALIGNMENT



CHECK RAIL ALIGNMENT



INSTALL LOW PROFILE GAS BLOCK AND GAS TUBE AFTER BARREL NUT IS INSTALLED



INSTALL MUZZLE BRAKE LAST
OPTIONAL: PXT PARA COMP

